



All resistors 1/4w 5% carbon
 * = parts not on PC board
 IR=International Rectifier
 IC=Teledyne Components
 LM=National Semiconductor
 NE=Signetics



SCHEMATIC TRACED BY
 TMSI C/O LEE A. HART
 814 8TH AVE. N.
 SARTELL, MN 56377
 leeahart@earthlink.net

Title PETROSONICS PWM CONTROLLER 500006-1 REV. C	
Size A	Document Number C:\ORCAD\SHEET\PETROSON.SCH
Date: July 11, 2001	Sheet 1 of 1

J1 A-E IS USED AS CURRENT SENSE RESISTOR



PARTS PLACEMENT (COMPONENT SIDE VIEW)